



Replace Silentblocks in aluminum Track control arms

Guidelines to replace a Silentblock in an aluminum Track control arm

Remove the silentblock

- Use the proper tools
(Sidem mounting tool kit for silentblocks R10060 KIT)
- Make sure the silentblock is pressed out straight
so that the hole is not deformed
- Clean the hole properly



Pressing in the new silentblock

- Apply appropriate glue in the hole and on the silentblock
(follow the prescriptions of the glue f.i. loctite 603)
- Use the correct tools to press in the silentblock
in the track control arm